


OWNER'S MANUAL



**LumiSource®**



Congratulations!

You are now the proud owner of a BOOM CHAIR™ 2.0. Prepare to experience your entertainment on a whole new level. BOOM CHAIR™ 2.0 allows you to **HEAR** the sound and **FEEL** the excitement. You'll experience every crash, bang, and boom while enjoying your favorite game, music, or movie. BOOM CHAIR 2.0™ is also a great game seat built to endure the rigors of today's gaming environment. Take a moment to review your owner's manual before connecting your BOOM CHAIR™ 2.0. Assembly and operation of the BOOM CHAIR™ 2.0 is simple.

If you need further assistance visit us at [www.BoomChair.com](http://www.BoomChair.com) or [www.LumiSource.com](http://www.LumiSource.com)

BOOM CHAIR™ 2.0 is designed and manufactured by LumiSource, Inc.  
2950 Old Higgins Road, Elk Grove Village, IL 60007

PATENTS PENDING

## READ BEFORE USE

- DO NOT wash or soak with water. If BOOM CHAIR™ 2.0 gets wet, disconnect power immediately and do not use until completely dry.
- Switch power off (0) and unplug BOOM CHAIR™ 2.0 when not in use.
- Children under 5 years old should not use this product without parental supervision.
- For INDOOR use only/ DO NOT expose to direct sunlight, moisture, or extreme temperatures.
- DO NOT use on slippery or uneven flooring.
- Excessive exposure to audio equipment at high volume may lead to hearing loss.
- DO NOT open bottom plate of the BOOM CHAIR™ 2.0 (see warning below).



*Internal*

- DO NOT OPEN

Caution: To reduce the risk of electric shock and fire, do not remove the bottom plate of the BOOM CHAIR™ 2.0. There are no user serviceable parts inside. Refer to your warranty for service information.

## FCC CERTIFICATIONS

This device complies with Part 15 of the FCC rules.


Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Power rating: 12 Volts at 3500/mA

## SET-UP GUIDE

The BOOM CHAIR™ 2.0 comes with the following:



### PARTS LIST:

- 1) BOOM CHAIR™ 2.0
- 2) AC/DC POWER SUPPLY
- 3a) RCA CORD  
(headphone jack to audio left & right channel connectors)
- 3b) RCA CORD  
(audio left & right channel connectors)
- 4) RECEPTACLE
- 5) HOOK & LOOP FASTENER
- 6) RUBBER CAPS
- 7) MESH POCKETS
- 8) RUBBER FEET
- 9) OUTPUT PANEL

### SYSTEM SPECIFICATIONS

BOOM CHAIR™ 2.0 MULTIMEDIA FURNITURE

Dimensions: 31.75" W x 26.25" L x 16.125" H

Weight: 50 lbs.





2 - 3" coaxial mid-high speakers @ 10W 4 Ohms

1 - 5" tube construction sub-woofer

1 - 20" vibration pad

1 - 12v AC/DC UL listed power adapter

# CONTROL PANEL



# ASSEMBLY INSTRUCTIONS

Step 1: Lift seatback to the upright position.

Step 2: Refer to diagram on far right for directions on securing upright position.


Step 3: Insert receptacle (4) into adapter (2).

Step 4: Plug adapter (2) into outlet.

Step 5: Flip power switch (A) to ON (I) position.

Step 6: Refer to pages 7 & 8 for connection to audio device.

SEAT BACK FOLDS DOWN




## CONNECTING TO GAME CONSOLES

*Note: All game consoles are supplied with a custom connector with yellow video out and RCA red/white audio out.*

- Step 1: Plug yellow composite video cable from game console into video input of TV. (Fig. 1)
- Step 2: Plug Red/White RCA cord from game console into RCA INPUT (E) of BoomChair™ 2.0. (Fig. 2)


*Alternate Connection:  
Connect directly from the TV Audio Out to the BoomChair™ Audio Input using the RCA audio cords provided.*



*Note: It may be necessary to extend your BoomChair™ 2.0 further away from your TV or console. Here's how. (Fig.3)*

- Step 1: Connect Audio Coupler (not included) to Red/White RCA cord from game console.
- Step 2: Connect one end of RCA cord (3b) into other end of Audio Coupler.
- Step 3: Connect other end of RCA cord (3b) into RCA INPUT (E) of BoomChair™ 2.0.

# CONNECTING TO HAND-HELD GAMES, MP3 PLAYERS & CD/DVD PLAYERS



Step 1: Plug the single end of the RCA cord (3a) into the headphone jack of your device.

Step 2: Plug the pair of RCA cords into RCA INPUT (E) on the BoomChair™ 2.0.

③a = headphone jack to audio left & right channel connectors.




## DAISY CHAINING CHAIRS TOGETHER : UP TO 4 CHAIRS

Step 1: Connect BoomChair™ 2.0 to any media device as described on pg. 7 or pg. 8. This is the first chair.

Step 2: Connect one end of RCA cord (3b) into RCA OUTPUT (G) of first BoomChair™ 2.0.

Step 3: Connect other end of RCA cord (3b) into RCA INPUT (E) of second BoomChair™ 2.0.

Repeat steps 2 and 3 from second chair to connect more BoomChair™ 2.0's.



## **TROUBLESHOOTING BOOM CHAIR™/BOOM CUBE™/BOOM CHAIR™ 2.0**

Q: Why isn't there sound coming from any of my speakers?

A: Ensure your Boom Chair™ 2.0 is connected as described in the Setup Guide. Check that the power to the unit is in the "ON" (I) position and the volume is turned up. Also, make sure your audio device is not set to "MUTE" and volume is turned up.

Q: Why isn't there sound coming from one of the speakers?

A: Ensure the audio cord to the Boom Chair™ 2.0 is securely connected as described in the Setup Guide. Make sure that both the left and right channel audio inputs and outputs are securely connected to the Boom Chair™ 2.0 and audio device.

Q: Why don't I feel any vibration?

A: Make sure the vibration control is switched on. The vibration is sensitive to volume and bass because it interacts with the music/game. Adjust the sensitivity of the vibration, volume, and bass according to your desired settings.

Q: Where can I get more information?

A: Visit us at [www.BoomChair.com](http://www.BoomChair.com) or [www.LumiSource.com](http://www.LumiSource.com)

Contact information: LumiSource, Inc. 2950 Old Higgins Road, Elk Grove Village, IL 60007

E-mail: [customerservice@lumisource.com](mailto:customerservice@lumisource.com)

## **MAINTENANCE AND REPAIR**

If a problem occurs while using this product, please contact us. DO NOT open unit or attempt to repair on your own. It may result in serious injury from electric shock and void your product warranty.

## **CLEANING/CARE INSTRUCTIONS**

Fabric: Use a clean cloth to dab lightly with soap and water. DO NOT rub.  
DO NOT immerse in water. DO NOT use detergent.

**NOTE: PLEASE DO NOT USE ON HARDWOOD FLOORS, IT MAY CAUSE SCRATCHING.**

## **LUMISOURCE, INC. LIMITED WARRANTY**

**LIMITED WARRANTY:** LumiSource, Inc. (“LumiSource”) warrants this product against defects in materials and workmanship for a period of ninety (90) days from the date of original consumer purchase. If a covered warranty claim is timely made, LumiSource will, at its sole discretion: (a) repair the product, using new and/or refurbished replacement parts or (b) replace the product with an identical (or comparable) product, without charge to you other than the initial shipping cost to return the product. LumiSource will only pay return shipping charges for destinations within the 48 contiguous U.S.A., if the returned product is covered by the limited warranty.

**WHAT THIS WARRANTY DOES NOT COVER:** This warranty does not cover defects resulting from accidents, alterations, unauthorized repair, failure to follow instructions, misuse, commercial use, fire, flood, or acts of God.


**WHAT WE ASK YOU TO DO:** If there is a covered defect, please write or email us within 90 days of the date of purchase at the address noted on page 8 to obtain instructions and authorization to return the product to LumiSource. You will need to pack the product securely in packaging providing at least the degree of protection of the original carton and packing materials and ship it to us at your expense. You will also need to include with the product (a) a copy of your original proof of purchase (retail receipt) showing the date of purchase and (b) a detailed explanation of the problem(s) requiring service.

**TO THE EXTENT PERMITTED BY LAW, THIS LIMITED WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, ORAL OR WRITTEN, EXPRESS OR IMPLIED. TO THE EXTENT PERMITTED BY LAW, LUMISOURCE HEREBY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT APPLICABLE STATE LAW EXCLUDES SUCH DISCLAIMERS, THEN TO THE EXTENT ALLOWED BY LAW, THE TIME FOR ANY CLAIMS FOR SUCH IMPLIED WARRANTIES SHALL EXPIRE 90 DAYS FROM THE DATE OF ORIGINAL CONSUMER PURCHASE. TO THE EXTENT PERMITTED BY LAW, LUMISOURCE IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF TIME, INCONVENIENCE, LOSS OF USE OF YOUR PRODUCT, OR PERSONAL INJURY OR PROPERTY DAMAGE, CAUSED BY YOUR PRODUCT OR ITS FAILURE TO WORK.**


This limited warranty gives you specific legal rights. Some states do not allow the exclusion or limitation of incidental or consequential damages, and applicable law may not permit the exclusion of certain implied warranties. You may also have their rights, which vary, from state to state.

CHECK OUT OUR OTHER BOOM AFFILIATED PRODUCTS:


BOOM CUBE™



BOOM CHAIR™ 2.0



BOOM CHAIR™



**LumiSource®**

2950 Old Higgins Road, Elk Grove Village, IL 60007

E-mail: [customerservice@lumisource.com](mailto:customerservice@lumisource.com)

[www.BoomChair.com](http://www.BoomChair.com) or [www.LumiSource.com](http://www.LumiSource.com)

Revised 02/01/06